What's New in SA

SA 2013.03.22

Closest Points between Two Surfaces

This command finds the closest points between two surfaces, which is particularly useful for determining clearance/interference for virtual fit-up and other alignment applications. From the menu, select **Construct>Points>Closest Points between 2 Surfaces**. Pick two surfaces and this creates two points, one on each surface, minimizing the distance between the two.

Relationship Fit Filters

A series of filters have been added to the *Minimize Relationships* dialog (see image below). This filter provides three options:

- Hide all Relationships not included in the fit. This will remove any unchecked (excluded) relationships from the *Minimize Relationships* dialog.
- Hide Geometry Relationships that are not included in the fit. Only geometry relationships that are unchecked (excluded) will be filtered out of the *Minimize Relationships* dialog.

 Check all Relationships (include all in fit). Selects (checks) all relationships in the collection for inclusion in the *Minimize Relationships* dialog.

Normalize Weighting	Degrees of Freedom (relative			💟 Rz	
Filters	Botate about working frameworking frameworking	me origin 🛛 😨	Rotate abo	ut centroid	Ш.
Weight	Relationship	[Max Obj]	RMS Obj	Max Mag	
2 1.000	Points to Fit Plane Fit Obj. Plane	6.1192	3.0072		Ц.
Relationsh	ip Fitting Display Filters				1
	de Geometry Relationships that an reck, all Relationships (include all in		_		6
				JK.	Canot
guations: 54, M	eck all Relationships (include all in ax Obj: 6.1192, RMS Obj: 3.0072			······) ()	Cance
puetions: 54, M Motion Compor Translation: X	eck all Relationships (include all in ax Obj: 6.1192, RMS Obj: 3.0072			······) ()	Cance
quations: 54, M Motion Compor Translation: X Rotation: R	eck all Relationships (include all in ax Obj: 6.1192, RMS Obj: 3.0072 vents 0.0000, Y 0.0000, Z 0.0000	n fit)		Show steps	Cance
quations: 54, M Motion Compor Translation: X Rotation: R Rus	eck all Relationships (include all in ax Obj: 6.1192, RMS Obj: 3.0072 ents 0.0000, Y 0.0000, Z 0.0000 0.0000, Ry 0.0000, Rz 0.0000	n fit) (Dpen F	Move J	Show steps Manually Report	Cance

Stock Language Translation-French

French is now included as a stock language in SA.

Geometry Relationship Storage

The results of geometry relationships are now stored in the SA file instead of being recalculated on open. This avoids potentially lengthy file open commands in certain cases which required a large number of geometry relationships to be recalculated.

SA Remote

You now have the ability to browse for available tracker interfaces, removing the need to manually key in an IP address.

Support for Wavefront Objects File (.obj)

Files formatted in Wavefront's .obj file format may now be imported via the File>Import>Custom Formats>Wavefront Objects File (.obj) menu command.

SolidWorks 2013 Support

SolidWorks 2013 file formats are now supported through the Direct CAD Access import option.

DXF Export

When exporting a .DXF file via File>Export>DXF File, there is now added support for exporting point clouds, as well as controlling whether or not point labels are included.

Direct CAD Access Settings: Reset to Defaults

In the *Direct CAD Access Settings* dialog, a new Reset to Defaults button restores the settings to factory defaults.

USMN Dialog

A number of minor improvements have been made to the USMN dialog. You can now right-click any instrument in the instrument list of the USMN dialog to access its properties or to check/uncheck all instruments. The point list has checkboxes for easily removing points from the USMN solution, and you can right-click any point in the point list to access its properties or to check/uncheck all points from the solution. Right click menu support has been added to the properties for the instrument list as well as the point list. Simply right click and you now have the option to select/unselect all. Check boxes have also been added to determine active points.

1.000 0.5A A. 0-API Tacker III 1000 1.5A A. 0-API Tacker III 1000 2.5A A. 2-Aesti Lace Redu (J.P.Div) 1.000 2.5A A. 3-Fac Tacker 1.000 2.5A A. 3-Fac Tacker 1.000 2.5A A. 3-Fac Tacker 1.000 2.5A A. 3-Fac Tacker	100	IF 1.000 IF 1.000 roperties heck All Incheck All If 1.000	5	677.8908 740.6429 934.0787 659.9032 1000.0606	905 935 065 035				0123 0123 0123
1.000 2 SA A: 2-Methic Lever Radar (LPDov) 1.000 3 SA A: 3-Faro Tracker 2007 Solver, Tein Duffers, and Re-Solve	- CO.	heck All Incheck All	1	934.0787 659.9032	061				
1.000 3. SA A: 3 - Faro Tracker	1 m	heck All Incheck All		659.9032					0122
to Solve, Triss Dutliers, and Re-Solve	U	Incheck All			83%				01 a.d
to Solve, Trin Outliers, and Re-Solve	U	Incheck All		1000.0606					0123
to Solve, Trin Outliers, and Re-Solve		1.000							0123
to Solve, Trin Outliers, and Re-Solve	,			1046.6029	72%				0123
to Solve, Trin Outliers, and Re-Solve	•		7	811.4360	72%				0123
		2 1.000	13	904.0971	66% 57%				0123
Auto Solve Do this automatically		1.000	10	996.0901	4011				0123
		2 1.000	12	016.5475					0123
	-								
Best Fit Only Instrument Setting	8. j.								
Best-Fit then Solve Tim Outliers									
Solve Exclude Measurements									
certainty Field Analysis									
Begin Samples: 300									
V TimeLink 40 mm									
Z Time Limit 4.0 mil	٩.								
porting									
	-								
Instrument Uncertainty Analysis CoVa	cii I								
Apply Results		No scale bars defined.					Scale Bax		
Create composite group: USMN Composite Create point uncertainty fields		Sumay							
		Point Enox Overall RMS = 359.3811, Average = 270.2559, Max = 1046.6028 '9'							
Apply instrument and point group transforms in SA									
De-Activate measurements weighted to zero									

Reporting Improvements

Pictures

Pictures within reports may now be rotated clockwise in 90 degree increments. Simply right-click an image and select **Rotate 90** from the context menu.

Templates

Report templates now support scale bars, so they can be added to a template (see below).

emplate Nar		
eportT emplate	1	
Report Instr	uctions	Properties for Selected Instruction
Type Rem	Summary Scale Bar: ::	Object Object Relationship Event Unstrument Custom Table Picture Scale Bar Select
		Collection
< Add Dutput Sele		
Add	Remove 1) Item
Add Dutput Sele Send to Curre	Remove 1) Item
Add Dutput Sele Send to Curre Embed SA Rep SA Do Send to Exter	Remove 1	Properties for Selected Output Type Collection

Movement Constraints

Object movement in a report can be constrained to the horizontal or vertical direction by holding the **SHIFT** key down while dragging an object. This permits more precise alignment and positioning on reports.

Copy/Paste

Report items can be copied/pasted using the new **Copy** and **Paste** context menu items (see below).

Export to Excel

Single and multiple items can be exported from an SA report to an Excel spreadsheet using the new **Export to Excel** context menu (see be-

low).

	Fram			
	A::WOR	ALD Y	Z	
Translation	0.0000	0.0000	0.0000	
Rotation deg.	0.0000	0.0000	0.0000	
X Axis	1.000000	0.000000	0.000000	
Y Axis Z Axis	0.000000	1.000000	0.000000	
Proj. Ang.	Rx from Y	Ry from Z	Rz from X	
X (deg.)	0.0000	90.0000	0.0000	
Y (deg.)	0.0000	0.(Report Option	5
Z (deg.)	90.0000	0.0	Remove from	
			Сору	
			Export to Excel	
			Bring to Front	
			Send to Back	
			Page Alignme	nt 🕨
			Printing Invisit	
			Locked Object	
			Remove Object	t Overlap
			Do Not Trunca	te
			Change Font	
			Properties	

Working Frame in Report Bar

The report bar now displays the name and collection of the working coordinate frame (see below).



Measurement Plan Improvements

In the **Utility Operations>Delay for Specified Time** command, you can now suppress the display of the progress dialog using the argument *Show* progress dialog?

The **Reporting Operations>Set Report Options for Object** command now supports relationships.

The Instrument Operations>Instrument Operational Check command supports several new operations:

 "Show Big Group/Target Window". Displays the resizable group/target window, which remembers its size and position onscreen. This will return SUCCESS if the dialog is already showing.

- "Close Big Group/Target Window". Closes the resizable Group/Target window if it is open.
- "API DI Enable iVision Single SMR". Enables iVision Single SMR mode.
- "API DI Enable iVision Multi SMR". Enables iVision Multi-SMR mode.
- "API DI Disable iVision". Disables iVision functionality.

A number of new commands have been added to Measurement Plans. These include:

- Variables>Set Collection Object Name Variable. This creates a variable of type collection object name.
- Variables>Get Collection Object Name Variable. This retrieves the value for a variable of type collection object name.
- Construction Operations>Callouts>Create Vector Callout. Creates a vector callout in a callout view.
- Construction Operations>Callouts>Create Point Comparison Callout. Creates a point comparison callout in a callout view.
- Construction Operations>Callouts>Create Relationship Callout. Creates a relationship callout in a callout view.
- Construction Operations>Callouts>Delete Callout View. Deletes a callout view.
- Construction Operations>Callouts>Rename Callout View. Renames a callout view.
- Utility Operations>Create Robot Calibration. Creates a robot calibration.
- Utility Operations>Delete Robot Calibration. Deletes a robot calibration.
- Utility Operations>Import Poses Match to Measurements. Imports a set of poses and associates them with measurements.
- Utility Operations>Perform Robot Calibration. Performs a robot calibration procedure.
- Utility Operations>Start/Stop Robot Calibration Trapping. Starts or stops measurement trapping for a robot calibration.
- Utility Operations>Make a Collection Instrument ID from a Collection and an Integer. Creates a value of type collection instrument ID from a collection and integer.
- Utility Operations>Make a Collection Machine ID from a Collection and an Integer. Creates a value of type collection machine ID from a collection and an integer.

- Utility Operations>Make a Collection Instrument ID Runtime Select. Prompts the user to select a single instrument, from which a collection instrument ID is retrieved.
- Utility Operations>Set Active Robot Calibration. Sets a specific robot calibration to be the active calibration.

Geometry Triggers: Concentric Cylinders

Concentric cylinders can now be used as geometry triggers in laser tracker, portable arm, and NDI OptoTrak instrument interfaces. Set *Closest Point* or *Interpolate* at the time of concentric cylinder creation.

Add Planes	Add Cylinders		Add Spheres
Cartesian Select	Concentric	Select	Select
Cylindric Cross Sampling		Cross Sampling Closest Pt	Cross Sampling Closest Pt.
Draw In SA	Concentric Along Watin	g Z-Axis	C Interpolate
Type Sample	Cylinders Begrining Radius 25 Ending Radius 10 Radial Spacing 76	16.0 mm	Delete
	Cross Sampling Interpolate	Closest Pt.	Delete
	Graphics - Coordinates o	n Z-Axis	
Output Point Grouping	Begin 0.0	mm	
📝 Group Separately (Append	T End 500.0) mm	
		OK	ОК

Remove Last Point Assignment

Remove Last Point can now be assigned to a function key in the instrument interface. This also means that this function can be assigned to a programmable remote, such as a T-Probe or RF Remote.

API Device Interface Upgrade

The API Device Interface has been updated to version 4.6.1.0. This version provides support for new Innovo camera functions, namely the ability to enable/disable the camera in single or multi-SMR mode.

TTL triggered data can also now be buffered as well. The buffer size can be set in the DI settings dialog.

All emScon Trackers

Updated the TPWizard SDK to v.2.0.0.4978 for AT-401 and AT-901 trackers. Results from all checks/compensations will be added to the instrument History in SA (right-click on the instrument in the tree, and select **History** from the context menu).

Deeper support for external triggering has been incorporated into the instrument interface, such as the ability to set the Minimal Time Delay, Clock Transition (positive or negative edge), and Trigger Start Signal (high or low active). For faster triggering (External Source and Event Trigger Mode), you need to run a measurement profile with a Temporal Scan acquisition, and be sure to note what the operation is sending to SA. For more information on external triggering, see the Laser Tracker notes in the Readme file for SA 2011.12.22.

Leica AT-401

Automeasure now uses a routine that improves speed of an automeasure operation.

A new outdoor measurement mode is supported, and can be toggled from the **Settings>Leica 4xx** menu. When on, this measurement mode overrides the FAST, STANDARD, and PRECISE modes, no matter which is set. This mode is used for all measurements until toggled off. (The Power Lock Mode settings—*Indoor, Outdoor <80m*, and *Outdoor >80m*—have been deprecated by this new Outdoor Measure Mode.

For other improvements, changes, and fixes, please refer to the SA Readme file.